

Building materials product recommendation

for Finland, Sweden & Norway

Version: 04/2004

System - partner:



Electrical floor heating T2QuickNet - self-adhering mat

Applications: Private bathrooms, shower areas, kitchens and livingrooms

Sub floor		Cement screed, Anhydrite screed	Wooden, dry mortar less screed*	Old tiles
Top floor		Tiles	Marble + Natural stone*	Tiles
Working steps	Product Type	Rescon Mapei AS Norway - Technical support: phone: +47 62 97 20 00 ; Rescon Mapei OY Finland - Technical support phone: + 358 986 78 900; Rescon Mapei AB Sweden - Technical support: phone: 08 660 71 35 ;		
1. Apply a primer	Dispersion based primer	Primer G	Primer G	Bonding primer Mapeprim 1 K + Quarzsand
2. Install electrical floor heating		Raychem T2QuickNet - self adhering -		
3. Level out unevenness (optional)	Self levelling material	Ultraplan Ultraplan Maxi	Ultraplan Ultraplan Maxi	Fiberplan Ultraplan Ultraplan Maxi
4. Apply water barrier (optional)	Waterproofing material	Mapelastik + DHT Dichtsystem	Mapelastik + DHT Dichtsystem	Keraquick + Latex plus Mapetexvlies Mapelastik+DHT Dichtsystem Mapelastik + DHT Dichtsystem
5. Lay ceramic tiles	Adhesive, improved with synthetics, classified as C2 according to EN 12004	Keraflex S1 Keraquick Mapestone1 Keraflex Maxi	Granirapid Keraquick Mapestone 1 Keraquick+Latex plus	Keraquick + Latex plus Keraflex S1 Keraquick Mapestone1
6. Apply grout between ceramic tiles	Grout filler improved with synthetics, classified as CG2 according to EN 13888 for ceramic tiles	Ultracolor	Ultracolor	Ultracolor
7. Apply rubberised grout between wall and floor	Silicone sealant	Mapesil AC	Mapesil LN	Mapesil AC

*) for more detailed information please contact Mapei direct

Tyco Thermal Controls N.V.
Staatsbaan 4A
3210 Lubbeek - Belgium

For Sweden - Tel.: +46 20-210100
For Norway - Tel.: +47 66-817990
www.raychemfloorheating.com



tyco
Flow Control

Tyco Thermal Controls