



Electrical floor heating T2ISOLECTA+ T2Quicknet

Application: Private bathrooms, shower areas and kitchen



Sub floor		Cement screed, Anhydrite screed		timber floor board, particle board*		Old tiles	
Top floor		Tiles	Marble + Natural stone*	Tiles		Tiles	
Working steps	product group	AKZO NOBEL Casco				Technical support Tel.:	
		0049 (0) 2363 399 - 0 (Region: Scandinavia - S, N, FIN)					
1. Apply a primer	Dispersion based primer	Casco Golvprimer	Casco Golvprimer	*)		Schönox PX	
2. Level out unevenesses (optional)	Self levelling surfacer	Cascoplan Thermoplan	Cascoplan Thermoplan	Cascoplan Thermoplan		Cascoplan Thermoplan	
3. Fixation Isolecta boards	Adhesive, improved with synthetics, classified as C2F according to EN 12004	CASCO Multifix Rapid	CASCO Multifix Rapid	CASCO Multifix Rapid		CASCO Multifix Rapid	
4. Install electrical floor heating		T2QuickNet - self adhering -					
5. embedding in filler (optional)	Self levelling surfacer	Cascoplan Thermoplan	Cascoplan Thermoplan	Cascoplan Thermoplan		Cascoplan Thermoplan	
6. Apply water proofing (optional)	Waterproofing	Casco Golvprimer/ Casco Auqastop	Casco Golvprimer/ Casco Auqastop	Casco Golvprimer/ Casco Auqastop		Casco Golvprimer/ Casco Auqastop	
7. Fixation ceramic tiles	Adhesive, improved with synthetics, classified as C2 according to EN 12004	Casco FloorFlex	Casco Multifix white	Casco FloorFlex		Casco FloorFlex	
8. Filling grouts between ceramic tiles	Grout filler improved with synthetics, classified as CG2 according to EN 13888 for ceramic tiles	Casco Flexo	Casco Flexo	Casco Flexo		Casco Flexo	
9. Filling elastic grouts between wall and floor	Silicone sealant	Casco sealing	Casco sealing	Casco sealing		Casco sealing	

*) for more detailed informations go in contact with supplier **Casco**

