

Building materials product recommendation

For United Kingdom
Version: 04/2004

System - partner:



Electrical floor heating T2QuickNet - self-adhering mat

Applications: Private bathrooms, shower areas, kitchens and living rooms

| Sub floor | | Cement screed, Anhydrite screed | timber floor board, particle board* | Old tiles |
|---|--|--|-------------------------------------|--------------------------------|
| Top floor | | Tiles | Marble + Natural stone* | Tiles |
| Working steps | Product type | PCI Construction Systems Ltd Technical support: phone: 0044 191 428 1717 (Region: Western Europe - UK) | | |
| 1. Apply a primer | Dispersion based primer | PCI Primer G PCI-Gisofix NT | PCI Primer G PCI-Gisofix NT | PCI Primer G PCI-Gisofix NT |
| 2. Install electrical floor heating | | Raychem T2QuickNet - self adhering - | | |
| 3. Level out unevenness | Self levelling material | PCI-Periplan | PCI-Periplan | PCI-Periplan |
| 4. Apply water barrier (optional) | Waterproofing material | PCI-Lastogum X | PCI-Lastogum X | PCI-Lastogum X |
| 5. Lay ceramic tiles | Adhesive, improved with synthetics, classified as C2 according to EN 12004 | PCI-Tilefast 6 Flex | PCI-Carraflex PCI-Carraflott | PCI-Tilefast 6 Flex |
| 6. Apply grout between ceramic tiles | Grout filler improved with synthetics, classified as CG2 according to EN 13888 for ceramic tiles | PCI-Groutfast 20 Rapidflex | PCI-Groutfast 20 Rapidflex | PCI-Groutfast 20 Rapidflex |
| 7. Apply rubberised grout between wall and floor | Silicone sealant | PCI Silcoferm S | PCI Silcoferm S | PCI Silcoferm S |

*) for more detailed information please contact **PCI**direct

Tyco Thermal Controls N.V.
Staatsbaan 4A
3210 Lubbeek - Belgium

Tel.: UK 0800 969013
Fax.: UK 0800 968624
www.raychemfloorheating.com

